



Furukawa - 0610011S - Batería Furukawa FTZ10-S Precargada

Voltaje: 12V - Amperaje: 9Ah. Se suministra con ácido incluido. Batería hermética pre-cargada

V

AH

CCA

POLARIDAD

SALIDA GASES

L

AN

ALT

12

9

130

Izquierda

150

87

89

Esta batería se presenta totalmente sellada y precargada, lista para ser instalada y sin la necesidad de añadir ´cido.

Pr´cticamente sin posibilidad de perdidas de ´cido

Reducci´n al mínimo el proceso de sulfataci´n

Ideal para motocicletas, ATV, motos de agua...

Ofrece un ´ptimo Cold Cranking (CCA)

NOTA: En caso de almacenaje prolongado revisar la tensi´n y recargar si es necesario, aconsejamos revisarlas en un plazo de 3-4 meses.



CHARGE INSTRUCTIONS
1. CHARGE IN A WELL VENTILATED AREA.
2. DO NOT OPEN THE BATTERY CAPS.
3. DO NOT SHORT THE TERMINALS.
4. DO NOT INHALE THE BATTERY VAPORS.
5. DO NOT TOUCH THE BATTERY TERMINALS.
6. DO NOT TOUCH THE BATTERY CASE.
7. DO NOT DRINK OR EAT FROM THE BATTERY.
8. DO NOT SMOKING NEAR THE BATTERY.
9. DO NOT USE OPEN FLAMES NEAR THE BATTERY.
10. DO NOT USE THE BATTERY IN A FIRE.
11. DO NOT USE THE BATTERY IN A CAR.
12. DO NOT USE THE BATTERY IN A MOTORCYCLE.
13. DO NOT USE THE BATTERY IN A BOAT.
14. DO NOT USE THE BATTERY IN A TRUCK.
15. DO NOT USE THE BATTERY IN A TRACTOR.
16. DO NOT USE THE BATTERY IN A FAN.
17. DO NOT USE THE BATTERY IN A LIGHT.
18. DO NOT USE THE BATTERY IN A TV.
19. DO NOT USE THE BATTERY IN A RADIO.
20. DO NOT USE THE BATTERY IN A PHONE.

super MF
VALVE REGULATED LEAD ACID BATTERY

⊕ **FTZ10S 12Volts** ⊖

CHARGE INSTRUCTIONS
METHODE DE CHARGE
1. CHARGE IN A WELL VENTILATED AREA.
2. DO NOT OPEN THE BATTERY CAPS.
3. DO NOT SHORT THE TERMINALS.
4. DO NOT INHALE THE BATTERY VAPORS.
5. DO NOT TOUCH THE BATTERY TERMINALS.
6. DO NOT TOUCH THE BATTERY CASE.
7. DO NOT DRINK OR EAT FROM THE BATTERY.
8. DO NOT SMOKING NEAR THE BATTERY.
9. DO NOT USE OPEN FLAMES NEAR THE BATTERY.
10. DO NOT USE THE BATTERY IN A FIRE.
11. DO NOT USE THE BATTERY IN A CAR.
12. DO NOT USE THE BATTERY IN A MOTORCYCLE.
13. DO NOT USE THE BATTERY IN A BOAT.
14. DO NOT USE THE BATTERY IN A TRUCK.
15. DO NOT USE THE BATTERY IN A TRACTOR.
16. DO NOT USE THE BATTERY IN A FAN.
17. DO NOT USE THE BATTERY IN A LIGHT.
18. DO NOT USE THE BATTERY IN A TV.
19. DO NOT USE THE BATTERY IN A RADIO.
20. DO NOT USE THE BATTERY IN A PHONE.

♻️ **Pb** ~~♻️~~ **Pb**

SAE **PP** > PP <

9.1Ah(20HR) / 130CCA

SIAM FURUKAWA CO., LTD.
MADE IN THAILAND